

CARE FOR CAMBRO® INSULATED TRANSPORT

CLEANING INSTRUCTIONS:

- Clean with a soft cloth, bristle brush and a mild commercial detergent. Sanitizing solutions are recommended.
- Do not use steel wool, abrasive pads, metal brushes, or any cleaners containing ammonia or bleach.
- Rinse with clean, hot water.
- If units go through a dishwasher, be sure latches do not get caught in racks or between pegs.
 Avoid latches coming in contact with inside walls of machine. Any gaskets should also be removed when lids go through the dishwasher.
- When cleaning beverage servers, clean faucet and spout with a thin brush and mild detergent.
 The spout should be disassembled periodically for thorough cleaning. (Remember to reassemble spout in proper order after cleaning to insure trouble-free use.)

TO REMOVE ANY LINGERING SCENTS AND STAINS:

Use an odor removing soak or sanitizer to remove scents and stains that can occur from holding products with strong odors.

- A diluted solution of 2-3 tablespoons of baking soda per gallon of hot tap water or 1 part lemon juice or vinegar to 4 parts hot water is also an effective way to remove lingering odors.
- Rinse thoroughly with hot water and dry.

CASTER MAINTENANCE

To be performed after unit has been washed or steam cleaned:

- 1. Grease swivel raceway of caster using a lubricant such as Lubriplate No. 930-AA, Keystone #84EPXLT multi-purpose grease or the equivalent. Moving "O" Ring or seal with finger, apply grease using a grease gun with a needle nose adapter or a tube-type applicator such as "Sta-lube" Moly-graph Assembly Lube. These can be obtained at most auto parts stores.
- 2. Use a light oil such as WD-40 on the nylon bushing at the hub. Check caster for any damage and test caster spin and swivel rotation before returning to service.